

# MULTIBAND IMAGING PHOTOMETER FOR SIRT Pocket Guide

## Basic MIPS Capabilities:

Imaging photometry at 24, 70, and 160  $\mu\text{m}$  and low resolution ( $R = 15 - 25$ ) spectroscopy between 55 and 96  $\mu\text{m}$ . A fine pixel scale option at 70  $\mu\text{m}$  (no change required for the other two bands), combined with precise subpixel sampling dither patterns, allow data processing to achieve "super resolution" imaging. A cryogenic scan mirror mechanism provides freeze frame scan mapping, efficient dithering, and other instrument capabilities.

## MIPS Instantaneous Fields of View:

24 $\mu\text{m}$	5.2x5.2 arcminutes
70 $\mu\text{m}$	5.3x5.3 or 2.6x2.6 arcminutes
160 $\mu\text{m}$	0.5x5.3 arcminutes (effective)
SED Slit	3.8x0.32 arcminutes

## Basic Sensitivities (low background):

5 sigma in 500 seconds on source

24 $\mu\text{m}$	185 $\mu\text{Jy}$
70 $\mu\text{m}$	1410/3000 $\mu\text{Jy}$ (Default/Fine scale)
SED	11 mJy @ 55 $\mu\text{m}$ , 14 mJy @ 95 $\mu\text{m}$
160 $\mu\text{m}$	10 mJy*; 3400 $\mu\text{Jy}$ **
*160 $\mu\text{m}$ is model dependent confusion limited.	
**no confusion.	

## The MIPS Astronomical Observation Templates:

### Photometry & Super Resolution

- Telescope staring mode imaging photometry

### Scan Mapping

- Freeze frame mapping in all three bands with constant telescope slewing

### Spectral Energy Distribution (SED)

- Low resolution ( $R = 15 - 25$ ) spectroscopy over 55 to 96  $\mu\text{m}$  (half power response points)

### Total Power Mode

- Zero level brightness of very extended emission

## The MIPS Detector Arrays:

24 $\mu\text{m}$	Si:As (IBC) 128x128 pixels; 2.45" 4.7 $\mu\text{m}$ bandwidth
70 $\mu\text{m}$	Ge:Ga 32x32 pixels; 4.9" or 9.9" 19 $\mu\text{m}$ bandwidth SED $R = 15 - 25$
160 $\mu\text{m}$	Stressed Ge:Ga 2x20 pixels; 15.8" 35 $\mu\text{m}$ bandwidth

## Saturation Limits:

Point source in 1 second (Jy); Extended source in 10 seconds (MJy/ster)

Band	Point Source	Extended
24 $\mu\text{m}$	6.4	500
70 $\mu\text{m}$ (default)	8	70
70 $\mu\text{m}$ (fine)	41	360
SED @ 55,70,95 $\mu\text{m}$	24,64,220	430@60 $\mu\text{m}$
160 $\mu\text{m}$	17	33



Prepared by:  
William B. Latter  
SSC/MIPS Instrument Support Team Lead  
6-21-00

